



To learn more about the Amino Amigo remote or setup, Call Gearheart TV Help Desk @ **606.478.HELP**

- 1 TV INPUT SOURCE SELECT:**
Changes video input on TV if remote is programmed with a TV infrared code.
- 2 TV/AUX POWER/STANDBY:**
Powers on or off TV if remote is programmed with a TV infrared code.
- 3 COLOR NAVIGATION:**
RED: Accesses recorded and scheduled show
GREEN: Access "All Shows"
BLUE: Access "All Movies"
YELLOW: Access "Live TV"
- 4 'A' BUTTON:**
Accesses replay of shows on current channel.
- 5 DVR FUNCTIONS:**
Pauses/plays, fast-forwards/rewinds, stops, and records shows and movies.
- 6 APPS:**
Accesses all Apps downloaded to the TV.
- 7 NAVIGATION AND OK:**
Navigates through the TV Now platform. Press 'OK' to make a selection.
- 8 BACK:**
Returns to the previous menu or state within current App. From live video, this key opens the Main Menu.
- 9 VOLUME (Up or Down):**
Increases or decreases volume levels on your audio device(s).
- 10 CHANNEL SELECT AND TEXT ENTRY:**
Enters channel numbers in the GUIDE or full screen video. Also used to manual text entry.
- 11 INFORMATION:**
Accesses program information and starts a recording.
- 12 SEARCH:**
Searches for programs using microphone voice search, text-field, or quick search.
- 13 INFRA-RED (IR) WINDOW:**
Communicates with TV and Amigo 7x box.
- 14 MICROPHONE:**
Recognizes voice commands for voice search.
- 15 STB POWER/STANDBY:**
Switches STB power on or into standby or off mode
- 16 'B' BUTTON:**
Launches menu of recently accessed programs and channels.
- 17 'C' BUTTON:**
Displays settings.
- 18 ELECTRONIC PROGRAM GUIDE:**
Launches the CHANNEL GUIDE (EPG) within the App.
- 19 HOME:**
Launches Android TV main menu, including access to Apps
- 20 GOOGLE ASSISTANT:** This button may have  or 
Launches voice-based Google Assistant search.
- 21 CHANNEL/PAGE UP AND DOWN:**
Selects previous and next available channels.
- 22 MUTE:**
Mutes the audio on your audio device(s) (TV, Audio System, or STB)
- 23 SUBTITLES/CLOSED CAPTION:**
Turns on/off subtitles and closed captioning.
- 24 LAST CHANNEL RECALL:**
Displays menu of recently accessed channels.
- 25 LOW BATTERY WARNING LED:**
Turns on when batteries need to be changed.

